



Electron Top Mfg.

rev 9/10/2010

Installation Instructions

Always Check Stock # and Color Before Starting Installation



**1995-01 Volkswagen Cabrio
VW 7660 Top
ST11 Blk/Blk Stayfast or Topline Material**

VW7660 ST11
Black/Blk
Stayfast **10 10**



DATE: 11/01 (MAKE LABELS) ONLY

VW7660 ST11

1995-02 Volkswagen
Cabrio

DATE: 11/01

(MAKE LABELS) ONLY



Electron Top Mfg.



These pictures show how to slide top into the awning rail trim stick. Starting from the drivers side working your way to the passenger side.



This is another view of the top pulled half way around the awning rail trim stick.



This picture shows the top almost fully pulled around the awning rail trim stick.



This is a view of the rear of the top after the top has been fully pulled around the rear of the trim stick.

Electron Top Mfg.



At the the front of the trim stick, pop-rivet the bottom of the quarter and the channel flap so that it hangs down into the car to channel the water.



Start to pull the top forward at this point in the installation.



This would be a good time to run the side cables through the wire sleeves of the top and attach them at the front of the side rails.



Lock in front of top and secure it to the header bow at this point in the installation.

Electron Top Mfg.



This picture shows the completed installation of the top and the front header bow.



Lay out the top's quarter channel flaps and cement them to the C pillar post as shown above in this picture.



Fasten elastic strap to frame.



Another picture at a different angle of elastic installation.

Electron Top Mfg.



This is pointing out the elastic strap that is on both sides of the car.



Position the elastic strap at the center of the top. Pop-rivet the strap to bow between top and headliner like in the picture above.



Pop-rivet the herculite vinyl strap to the side-rail of frame of the top like the picture above.



Do the same on the other side of the top by pop-riveting the vinyl strap to side rail of the frame.

Electron Top Mfg.



Latch the front of the top down and cut a hole around back window frame. Make sure that you leave enough material to reach the window ring.



Starting from the bottom of the window frame, staple bottom of top to window frame tacking strip. Work your way around until the whole top is stapled to the window frame.



Carefully reinstall the rear window. Reconnect the defroster wires making sure that the clips do not get broken or bent.



You should have a smooth finished installation like the picture above.